

M'AXA常設機材リスト

PA equipment

■ CONSOLE

YAMAHA M7CL-48	1	digital,with PW800W
----------------	---	---------------------

SPEAKER

EV DeltaMax DML1152	6	house sp
EV DeltaMax DML2181	2	house sp (sub-low)
EV TX1152FM	6	fb sp
BOSE 802 II	2	side fill

■ POWER AMP

Accuphase PRO-6	4	for house sp
QSC MX1500a	2	for house sp (sub-low)
YAMAHA PX10	4	for fb sp

■ EFFECTOR

Roland SDE-3000A	1
Lexicon PCM60	1

■ MIC

SHURE SM58	5
SHURE SM57	6
SHURE BETA58A	4
SHURE BETA57A	5
SHURE BETA56A	5
Audio-Technica ATM-25	1
AUDIX I5	1
AUDIX D2	2
AUDIX D4	1
SENNHEISER MD421	2

■ CONDENSOR MIC

AKG C-451B	4
AKG C-3000	1
SHURE BETA91	1
AUDIX ADX51	2

■ DI

COUNTRYMAN Type85	3	
COUNTRYMAN Type10	2	
Radial PRO D2	1	Passive 2ch
Boss DI-1	4	

■ MIC STAND

K&M ST210	10
K&M ST259	13

■ CD/MD PLAYER

TASCAM CD-1	1
TASCAM MD-CD1	1

LIGHTING equipment

■ CONSOLE

SCENE SETTER-48	1	DMX
-----------------	---	-----

■ UNIT

Lite-Puter DX-1220	1	20A×12
--------------------	---	--------

■ PAR-LIGHT

64PAR 500N	5	
56PAR 300N	13	
56PAR 300M	12	
56PAR 300W	4	

■ LED

ELF-PAR46QUAD	4	
---------------	---	--

INSTRUMENTS

■ GUITAR AMP

Fender TWIN REVERB	1	re-issue (master volなし)
Roland JC-120	2	
YAMAHA G-50	1	
Marshall 1960A (キャビネットのみ)	1	※有料

■ BASS AMP

Hartke 3500&4.5XL	1	10inch*4&4inch*1
-------------------	---	------------------

■ DRUM SET

YAMAHA YD7000	1	bd22"/ft16"/tt12"&13"
---------------	---	-----------------------

■ KEYBOARD/STAND

YAMAHA S90XS	1	88鍵 piano touch ※有料
Ultimate AX48B	1	2段
YAMAHA LG-100	1	4-legs,table type

©新規購入、故障・破損等による代替え等、仕様や員数に変更になっている場合があります。